TECNOLUMEN

TECNOLUMEN GmbH & Co. KG • Lötzener Str. 2-4 • D-28207 Bremen • Tel (0421) 430 41 70 • Fax (0421) 4986685

Assembly instructions and important information BST 23

Technical details:

Power supply: 110-240 V / 50-60 Hz Maximum wattage (thermal): Recommended bulbs: Bulb socket: E27

Protection class: I 75 W globe-energy-saving bulb 23 W

<u>Note:</u> This specified maximum wattage applies to conventional bulbs. Since these have however been off the market since 01.09.2009, we recommend energy-saving bulbs with about 1/5 of the specified wattage. **Halogen bulbs are not suitable** because these become much hotter than conventional bulbs.

Safety instructions:

- Never cover the luminaire with a cloth fire hazard!
- Always ensure that the plug is removed from the socket before working on the luminaire or changing the bulb.
- Have repair work performed only by an authorized electrician, because electrical power can cause severe injuries!
- Some of the lamp components may get very hot in operation! Avoid skin contact with these components to prevent burns.

Care of lamp:

Use a standard commercial cleaner for the glass plate.

For cleaning the painted base plate only use a damp micro fibre cloth.

In the course of time a silver-colored patina forms on the nickel plated metal parts, which is frequently desired. If you want him surface to retain a glossy nickel-plated finish for reasons of appearance, use a polish without abrasive agents.

Mounting the footplate:

Please note the leaflet enclosed with the footplate:

"Assembly instructions for the footplate BST 23"

Mounting the glass plate:

Turn the upper nickel-plated retaining ring off the head piece. Put the glass plate onto the lower retaining ring with the matt side up. Then screw the upper retaining ring on again.